

WMC110 UF010

Hollow fiber ultrafiltration module for water and
wastewater applications

WMC110 UF010

General Information

The WMC110 UF010 is a tight ultrafiltration module, used for potable water production, RO pretreatment, municipal and industrial wastewater treatment. These modules excel in removing colloidal silica, turbidity, suspended solids, and virus and bacteria while offering outstanding pH and chlorine resistance and excellent mechanical strength of the fibers. The WMC110 UF010 modules can be used as final polishing step – for example to remove colloidal silica from boiler feed water or in the soft drink industry.

Membrane characteristics

Membrane material	Modified PES
Membrane fiber inner diameter	0.7 mm (0.028")
MWCO ¹	10 kDa
Filtration mode	Inside-Out; Vertical
Operation mode	Dead-end or cross-flow

Operating Conditions

Typical flux	50 – 100 l/m ² /h (30 – 60 gfd)
Backwash flux	100 – 250 l/m ² /h (60 - 150 gfd)
Max. system pressure	6 bar (87 psi)
Max. filtration transmembrane pressure	6 bar (87 psi)
Max. backwash pressure	4 bar (58 psi)
Max. active chlorine concentration	500 ppm @ pH>10
Max. cumulative active chlorine exposure	250,000 ppm-hours @ pH>10
Max. particle size	150 µm
Max. TSS	300 ppm
Max. turbidity	150 NTU
Max. Temperature during operation & cleaning	40°C (104°F)
pH range during operation	2-12
pH range during cleaning	1-13

¹ Molecular Weight Cut Off (MWCO) is an estimation as it depends on size, shape, charge and polarity of the compound being tested, as well as test conditions. Testing was done with PEG.

WMC110 UF010

Module Specification – Union

Materials of Construction

Housing	PVC-U
Potting	Epoxy resin

Dimensions

Membrane Surface Area	14.7 m²
L1.0	1546 mm (60.87")
L1.1	132 mm (5.20")
L2.0	1678 mm (66.08")
L2.1	61 mm (2.40")
D1.0	110 mm (4.33")
D1.1	1.0" BSP
D1.2	5.0" BSP
D2.0	110 mm (4.33")



Assembly Components

(1) Module	WMC110 UF
(2) Union end	TP 110mm Union End
(3) Nut	TP 110mm Wartel
(4) O-ring	TP End Cap O-ring 110mm

Available Sets

(Components 1-4)

WMC110 UF010 Union Set

WMC110 UF010 Union US Set ⁵

Set-Code	SETUF0023	SETUF0037
----------	-----------	-----------

⁵ US Sets include additional transition pieces (not shown) for permeate and feed/concentrate connections to allow for connection to standard US piping (permeate: 1"; feed/concentrate; 2.5"). For further information, please contact your local sales representative.



WMC110 UF010

Storage Information

New modules in original packaging can be stored for max. 1 year from shipping date in a dry place, protected from sunlight or any heat source, at temperatures between 1 and 40°C (33 and 104°F);

Ex-factory storage solution: 84wt% water, 15wt% glycerin and 1wt% sodium metabisulfite;

Weight Information

Weight

WMC110 UF010 Union Set

Empty weight Module including assembly components	11 kg (24 lbs)
Filled Module including assembly components	23.5 kg (52 lbs)

Shipping Information

Each module is individually packed in a vacuum sealed plastic bag. Modules and assembly components are shipped in the same cardboard box:

- Shipping weight per box: 15 kg (33 lbs.);
- Box dimensions: 180 x 25 x 25 cm; 70.9 x 9.8 x 9.8 in (L x W x H);

PCI Membranes Sp. z o.o.
ul. Polna 1 B
62-025 Kostrzyn Wielkopolski k/Poznan, Poland

Institutenweg 35
7521 PH Enschede
The Netherlands

www.pcimembranes.com

www.nxfiltration.com

The statements, technical information and recommendations contained herein are believed to be accurate at the date of publication. Since the conditions and methods of use of the product and/or the information referred to herein are beyond our control, NX Filtration B.V. expressly disclaims any and all liability as to any results obtained from or arising out of any use of the product and/or reliance on such information. NO WARRANTIES OR GUARANTEES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OF TITLE, OF NONINFRINGEMENT OF THIRD-PARTY RIGHTS OR ANY OTHER WARRANTY ARE MADE CONCERNING THE PRODUCTS DESCRIBED AND/OR THE INFORMATION PROVIDED HEREIN.

©2025 NX Filtration B.V. | All rights reserved worldwide